



Magnifying LED Lamp for floor & table




Assembly and Operation

Connect bottom pole to base, middle pole to bottom pole, and top pole to middle pole, rotating poles clockwise to secure them in place.

When assembled, the lamp head can be angled between 90 and 180 degrees as desired. (See diagram below for visual details)


Connect the power cable to 5V~2A adaptor, press the switch on the power cable to turn on/off light and dim the light you need.

Product Structure Diagram



(When adjusting the lamp head, please take care not to play with or over adjust the neck. It will hold up to normal use adjustment but excessive adjustment may result in loss of neck tension).

Assembling steps



Product Specification

Lumen: 500lm
Color temperature: 3000-6500K
Rating Power: 10W
Magnifier: 3X & 8X
Output: 5V-2A
Ra: >80

Packing List

1 x Lamp
1 x Power adapter
1 x User manual

Maintenance/Use/Troubleshoot

1. Do not expose to direct sunlight, humidity, rain, or corrosive gas.
2. Do not use alcohol, gasoline, isoamyl acetate, or toluene to clean the lamp, and do not spray paint or any chemicals on the lamp - this may cause lamp material to become discolored or corroded.
3. When cleaning the product, wipe it with a soft cloth, and **Do Not** rinse or immerse in water.
4. For your safety, please turn lamp off before conducting any inspection.
5. The lamp should be used on a flat stable surface only.
6. When adjusting the lamp head, please take care not to play with or over adjust the neck. It will hold up to adjustment during normal usage, but excessive adjustment may result in loss of neck tension.